



The Buttolo


Instructions For Use




To use the buttolo call take the call in your hand so that your thumb is in the middle of the call.



A light press on the call should let out the natural "Fiep" sound.



For the sound of a scared deer (bark), press stronger and quicker, until your thumb is at the bottom of the call. Pressing too strong could cause damage to delicate whistle parts.



The call should start when pushed to the point shown in the diagram. To alter the sound, block the holes on the side of the call with your other hand.

Best Practice

2 "Fiep" sounds in 3 seconds wait 10 seconds then 3 presses within 3 seconds followed by 10 second wait then two presses again.

Pause for 2 to 3 minutes then repeat and stay as quiet as possible.

Scared deer (bark)

Press to bark once wait 5 seconds, then 3 times with 3 second intervals wait 5 seconds followed by 3 times with 3 second intervals with these final 3 should be stronger while shaking the call.

Repeat after 2 minutes.

